

Step 1: CUTTING SINK OPENING

Carefully measure the perimeter of the sink frame of the sink you received, then add 1/64" to all four sides. This is the dimension of the sink opening to be cut on the countertop. [See diagram below.](#)

*** PROFESSIONAL STONE FABRICATOR USING CNC ROUTER OR WATERJET ARE PREFERRED TO PERFORM THIS SINK CUTOUT.**

*** THE SINK CAN BE CUT BY PROFESSIONAL STONE FABRICATOR USING WET SAW CUTTING METHOD.**

*** FOR CNC FABRICATORS YOU CAN DOWNLOAD DXF FILE FOR THE SINK YOU ARE INSTALLING FROM OUR WEBSITE.**

